


TDFN10-22



U	=	Plant code special symbol placed above part number
PN	=	Part number
C	=	Year / week code year = character orientation week = character
—	=	Lot code special symbol placed above or below the year / week code
●	=	Pin 1 indicator