




SMF400 FRED Pt[®]



1st row

First digit = Year (E = 2013; F = 2014; G = 2015; H = 2016...)

Second digit: Month (1 = Jan; 2 = Feb; ... O = Oct; N = Nov; D = Dec)

2nd row

First digit: Current/Voltage Rating

		VOLTAGE RATING (V)				
		100	200	300	400	600
CURRENT RATING (A)	1	A	D	G	K	N
	2	B	E	H	L	P
	3	C	F	J	M	Q

Second digit: Family: H, U, X, L

(No logo)