



Minicast Photomodule Holders, Cuts, and Bends

HOLDER	D	H	W	X	VIEW	TYPE
CC	10.5	16	7.3	16	Top	Holder
PA	8.5	14.1	6	11	Side	Holder
PC	9.3	12.7	7.3	9.6	Side	Holder
ES	8.25	19.6	7.2	16	Side	Holder
CZ	9.65	9.4	6.5	9.4	Top	Holder
CA	8.5	9.1	6	6	Side	Holder
CE	8.5	9.1	6	6	Side	Holder
CUT OR BEND	D	H	W	X	VIEW	TYPE
SB	9.65	20.8	5	6.95	-	Bend
DB	-	9.95	5	7.25	-	Cut
ST	9.65	5	5	6.95	-	Bend
SU	9.65	3	5	6.95	-	Bend
SO	10.1	9.6	5	7.4	-	Bend
SJ	10.1	19.25	5	7.4	-	Bend
DD	-	11.05	5	8.35	-	Cut
DH	11	9.6	5	8.3	-	Bend
DJ	12	4	5	9.2	-	Bend

