Vishay Spectrol

## **Mounting Instructions**

## **PRINCIPLES OF OPERATION**

The inner scale of the Model 25 Multidial is graduated in hundredths of a turn. The outer scale (read through the view window) counts the number of turns (0 to 20) that have been completed.

Example: If the number in the window reads 7 and the inner scale reads 22, the reading is 7 turns plus <sup>22</sup>/<sub>100</sub> of the eighth turn. In case of a 10 turn potentiometer, this equals 72.2 % of 10 turns.


Each complete revolution of the inner scale transfers the outer scale numerals in the window. Numeral transfer on the outer scale occurs between 97 and 0 on the inner scale. If two numerals appear in the window at the instant of transfer, read the lower of the two.

## **MOUNTING INSTRUCTIONS**

The following instructions apply when the Model 25 Multidial is used on a  $^{1}/_{8}$ " panel in conjunction with Spectrol 500 or 800 series potentiometers or other rotary components.

Using the existing anti-rotation lug

- 1. Drill a 3.18 mm (0.125") diameter hole 14.27 mm (0.562") below the horizontal centerline of potentiometer mounting hole.
- 2. Mount potentiometer shaft counter clockwise to obtain minimum resistance or voltage ratio. This is not necessarily identical with the mechanical stop.
- 3. Loosen set screw in knob of dial. Set dial to "0.0" reading.
- 4. While holding outer ring of dial, position unit lightly against panel. Tighten knob set screws to potentiometer shaft.







www.vishay.com

Vishay Spectrol

## Using the anti-rotation device:

- 1. Remove anti-rotation lug from dial by using pliers.
- 2. Mount potentiometer in panel with anti-rotation device nut (supplied with dial) and lock washer (supplied with potentiometer).
- 3. Turn potentiometer shaft counter clockwise to obtain minimum resistance or voltage ratio. This is not necessarily identical with the mechanical stop.
- 4. Loosen set screw in knob of dial. Set dial to "0.0" reading.
- 5. While holding outer ring of dial, position unit tightly against panel. Tighten knob set screw to potentiometer shaft.

